

User Manual

AntarView Lite Mobile Client

Version: 1.0.1

Date: December 2018

Contents

1 Introduction and Installation.....	3
1.1 Product Introduction.....	3
1.2 Operating environment.....	3
1.3 Software installation.....	3
1.4 Uninstalling.....	3
2 Software Startup.....	4
2.1 Interface introduction.....	4
2.2 Live Interface.....	4
2.3 Slide Menu.....	6
3 Device Management.....	6
3.1 Add a device.....	6
3.2 Device State.....	7
3.3 Delete a Device.....	7
3.4 Modify a Device.....	7
3.5 Check Device Information.....	8
3.6 Channel manage.....	9
4 Preview Management.....	11
4.1 Window Division.....	11
4.2 Screenshots/ Records/ Audio Control.....	12
5 Remote Configuration.....	12
5.2 Time Settings.....	13
5.3 Encode Settings.....	14
5.4 Record Settings.....	15
6 Remote Playback.....	16
6.1 Remote playback interface.....	16
6.2 Start playback.....	17
6.3 Playback control.....	17
7 Event Center.....	18
7.1 Push Configure.....	18
7.2 Notification.....	18

1 Introduction and Installation

1.1 Product Introduction

AntarView Pro can be installed in mobile devices running Android 4.0/ iOS 6.0 or above. Our software supports cloud platforms. Once you log in to your cloud account, you may manage the device which is bound to your cloud account and other operations mentioned above.

AntarView Pro Mobile APP supports WIFI, 3G/4G network connection. You are advised to connect the device to a public network and enable the AntarView Pro function, which is enabled by default, before managing the device.

Notes:

- Wi-Fi, 3G or 4G data connection is required.

1.2 Operating environment

Android: Android 4.0 and above.

iOS: IOS 6.0 and above.

1.3 Software installation

1. Log in to our official website, download the software to your PC and copy that to your cell phone for installation.
2. Log in to Google Play/ App Store, search and download “AntarView Pro Mobile” for installation.
3. Scan the QR code as shown below with your mobile phone to download and install the software.




Figure 1.1 Platform Network Management

1.4 Uninstalling

Specific steps are as follows:

1. Enter the mobile application management interface (set Application Management application);
2. Click on the icon of AntarView Pro Mobile Software, enter the application information interface;
3. Click on "Uninstall", then confirm uninstalling the software.

2 Software Startup

2.1 Interface introduction

The following interface will appear when you use our application for the first time.



Figure 2.1 Adding a device

You should input the serial number of the device before adding or scanning the QR code from the device. You may customize the device name and set the username and password for the device. For future login, the username and password is required and must be correct. After inputting all the information, tap "Preview" to enter the preview interface.

2.2 Live Interface

You may access remote playback, device management, event Center, remote control, local library, individual centers, system configuration and other modules on the live interface as shown in Figure 2.2.



Figure 2.2 Live Interface













ICON	Description	Introduction
	Switch Device	If you have added more than one device, tap this button to select a device which needs further operation.
	QR Code	Tap this button to enter the “Add device” interface to add a device.
	Playback	Tap this button to enter the “Playback” interface.
	Previous Page	Tap this button to enter the previous page of channels.
	Next Page	Tap this button to enter the next page of channels.
	Split Windows Switch	Tap this button to enter or exit the split views mode of display.
	Screenshot	Tap this button to capture the live screen.
	Video Record	Tap this button to start video recording.
	Split Windows View	Tap this button to select “Split Screen mode” to preview.
	Voice Signal Switch	Tap this button to enable or disable voice signal.
	Voice Talkback	Tap this button to enable or disable voice talkback.
	Slide Menu	Tap this button to view the slide menu.

Table 1.1 Buttons Introduction

2.3 Slide Menu

Tap the slide menu icon or slide from the left side of the screen to access the slide menu.



Figure 2.3 Slide Menu

1. Remote config: tap the remote config button to set the configuration of the device added.
2. Local config: tap the local config button to set application's configuration.
3. File manage: tap the file manage button to manage files, such as snapshots, recorded videos.
4. Device manage: tap the device manage button to add and delete devices.
5. Push config: tap the push config button to set the rules for messages received from devices.
6. Message notice: tap the message notice button to check and manage message you have received from the devices.
7. Help: tap the help button to obtain instructions on specific operations you need.
8. About: tap the about button to check the basic information for this application, such as version info.

3 Device Management

3.1 Add a device

Tap the "Device Management" button to access the relevant interface, as shown in Figure 3.1.



Figure 3.1 Interface of "Device Management"


Tap the  button to "add" a new device, as shown in Figure 3.2.




Figure 3.2 Interface of "Add Device"

Option	Description
Serial number	Input the device's number you want to add manually, or scan the device's QR code to automatically fill the serial number.
Device name	You can customize the device name to display on the application.
Username	Input the username to log in.
Password	Input the corresponding password.
Username	Input the corresponding username.
Preview	Fill in the above information, tap this button to access preview.

3.2 Device State

Tap the "Device Management" button to access the management interface, as shown in Figure 3.1. If the color of  button is green, the device is online; otherwise, it is offline.

3.3 Delete a Device

Tap the "Device Management" button to access the management interface, as shown in Figure 3.1. Tap the  button and confirm to delete the corresponding device at the pop-up window.

3.4 Modify a Device


Tap the "Device Management" button to access the management interface as shown in Figure 3.1. Select the device you need to modify and tap the  button to enter the interface and modify the information. As shown in Figure 3.3, modify the information and tap the "Preview" button to save the changes.



Figure 3.3 Interface of modifying a device

3.5 Check Device Information


Tap the “Device Management” button to access the management interface as shown in Figure 3.1. Select the device you need to modify and tap the  button to access the interface as shown in Figure 3.4.



Figure 3.4 Interface of “Device Info”

Tap “Basic Info” to check the basic information of the device. Here is an example.



Figure 3.5 Information of a connected NVR device

Tap “Channel State” and select the channel number to check the channel state of the corresponding device. Here is an example.



Figure 3.6 State of channel 3

Tap "Network Info" to check network information of the device. Here is an example.



Figure 3.7 Network information of a connected device

Tap "Disk Info" to check disk information of the device. Here is an example.



Figure 3.8 Disk information of a connected device

3.6 Channel manage

1. Live video: go to preview interface, select a device you want to control, tap the corresponding number as shown in Figure 3.9, the corresponding channel's video will then be played on the interface.



Figure 3.9 Interface of live video



2. Save as Favorite: Tap the channel number to play the live video, tap  to save it as favorite.
3. Adjust video quality: Select a channel to view the corresponding video, tap the video panel to access a menu, as shown in Figure 3.10, then tap  button to select video quality mode; SD is standard mode, while HD is high definition mode.



Figure 3.10 Video quality adjustment



4. PTZ Control: Select a channel to display the corresponding video, tap the video panel to access a menu, as shown in Figure 3.10, then tap  to get the navigation to control the PTZ camera.



Figure 3.11 PTZ Control

5. Full Screen: Select a channel to display the video, tap the video panel to access a menu, as shown in Figure 3.10, then tap  to enter the full screen mode.






Figure 3.12 Full-screen interface

4 Preview Management

4.1 Window Division

Go to the “Live” interface, tap  to select a device you want to preview.

1. Single channel mode: the default mode is “Single” mode, tap a channel number to play the live video.

2. Multiple-channel mode: tap  button to select the numbers of channels which play videos at the same







time. There are two multiple-channel modes:  represents 4 channels and  represents 9 channels, as shown in Figure 4.1. Tap the interface on play panel and select a channel by tapping the number, then set other channels in the same way.



Figure 4.1 Interface of viewing multiple-channel live videos

4.2 Screenshots/ Records/ Audio Control

1. Screenshots: On the preview interface, click on  to capture the screenshot of the play panel.
2. Records: On the preview interface, click on  to organize the plan for video recording.
3. Audios: when a preview channel is selected, tap  on audio previews to listen to the audio received by the camera.
4. Voice intercom:
 - (1) A preview channel is selected;
 - (2) Tap  to activate voice intercom: if the channel corresponding to the device does not support voice intercom, you may to activate this feature.

5 Remote Configuration

Tap the “Remote Settings” button on the slide menu and select a device you need to configure remotely. There are four functions which you may check and modify, as shown in Figure 5.1.



Figure 5.1 Function panel

5.1 General Settings

Tap “General Settings” in the panel as shown in Figure 5.1 to view information as shown in Figure 5.2.

- Modify the device name according to your preference.
- Modify the device ID according to your preference.
- Modify the output resolution according to your preference.
- Modify the 485 device according to the actual conditions.


Tap  to save the parameters after completing the configuration.



Figure 5.2 General Settings

5.2 Time Settings

Tap “Time Settings” in the panel as shown in Figure 5.1 and go to the settings panel as shown in Figure 5.3.







Figure 5.3 Time Settings

You have multiple choices to configure the time for remote devices.

- Check the check-box for “Sync with mobile”, tap  to start synchronizing the time; the time at remote devices will be the same as your mobile phone.
- Enable NTP and input NTP server domain name, tap  to start synchronizing the time with the NTP server.
- Enable DST and set the starting time and ending time, tap  to save the configuration.


5.3 Encode Settings

Tap “Encode Settings” in the panel as shown in Figure 5.1 and go to the settings panel as shown in Figure 5.4.



Figure 5.4 Encode Settings

Options	Descriptions
Channel NO.	Select the channel number
Encode Settings	Main Stream/ Sub Stream
Stream Type	Video Stream/ Video & Audio Stream
Resolution	The front-end device's resolution
Bit Rate Type	CBR/ VBR
Bit Rate Limit	Select the recommended bit-rate according to the front-end device
Frame Rate	Select a number or FULL (25fps and above)
Image Quality	Best/ Second Best /Better /General /Poor /Worse
Encoding Type	H264/ H265
I Frame Interval	Input a number according to your configuration

Tap  to save the parameters after completing the configuration.

5.4 Record Settings


Tap "Record Settings" in the panel as shown in Figure 5.1 and go to the settings panel as shown in Figure 5.5.

Options	Descriptions
Channel NO.	Select the channel number
Record Mode	Stop Record/ Time Record/ Alarm Record/ Time & Alarm
Week	Monday to Sunday
Time Segment	Set periods in one day
Pre-Recorded time	Start recording before the time stamps or alarm events

Record Delay	Continue recording after the time stamps or alarm events
--------------	--




Figure 5.5 Record Settings

Tap  to save the parameters after completing the configuration.

6 Remote Playback

The software enables users to play videos recorded on the device. It is easy to search for videos recorded by different channels in different time. You may play back the videos, video clips, and more.

6.1 Remote playback interface

Enter the homepage and tap  to go to the "Playback" interface, as shown in Figure 6.1.








Figure 6.1 Interface of remote playback

6.2 Start playback


Enter the homepage, tap a number to select a channel, tap  to go to the "Playback" interface as shown in Figure 6.1; then select day and time, and tap the play button to start playback.

6.3 Playback control




1. Recording

Tap ,  will then appear on the left corner of the preview screen, tap  again to end recording. The recorded media files will be saved in the mobile album.



2. Screenshots

Tap  and complete capture operations. The captured files will be saved in the mobile album.



3. Pause/Play

Tap  to start playing the video. The button will then change to ; tap  to stop playing.

4. Rewind/ fast-forward

In the playback mode, tap  to rewind the video; tap  to play fast-forward.

5. Audio preview


In playback mode, tap  to turn on the audio; after that, the icon will change to , then the audio

preview will be closed.

7 Event Center

Enter the slide menu, access "Push configure" to set the rules for receiving notifications; tap "Notification" to check and manage received messages.

7.1 Push Configure

Tap "Push configure" on the slide menu, select a device you want to make configuration to access the interface as shown in Figure 7.1. Enable and disable items as needed and tap  to save.




Figure 7.1 Push setting

Choose the device which supports the alarm push function. Turn on the switch. After that, the alarm information will be pushed to the phone and will be shown on the notification bar.


Types of push alerts include: video loss, video occlusion, perimeter protection, facial detection, external alarm and so on.

7.2 Notification

Tap "Notification" on the slide menu to check the received messages as shown in Figure 7.2.

Tap "Notification" to view the details;

Tap  to delete all messages;

Tap  to mark the messages as read.




Figure 7.2 Notification Panel